





6" Balustrade System Top Rail



Part Number	Length	Baluster Rail Installation Kit* <small>(See Installation Guide Page 33)</small>	
BTR6X96	96"	BRK6-7	
BTR6X144 <small>Note: Max. rail span distance for field applications is 96."</small>	144"	BRK6-7	

*Connects both ends of one 6" Rail to applications.
May be used for corner or butt connections into NP8X48 or PP8X96.
(2 qty.) 4" wide x 1 1/2" x 2" Angle Brackets.
(8 qty.) #14 x 2 1/2" Stainless Steel Flat Head Screws.




6" Balustrade System Bottom Rail



Part Number	Length	Baluster Rail Installation Kit* <small>(See Installation Guide Page 33)</small>	Rail Support Block <small>(See Below)</small>
BBR6X96	96"	BRK6-7	RSB4X4X6
BBR6X144 <small>Note: Max. rail span distance for field applications is 96."</small>	144"	BRK6-7	RSB4X4X6

*Connects both ends of one 6" Rail to applications.
May be used for corner or butt connections into NP8X48 or PP8X96.
(2 qty.) 4" wide x 1 1/2" x 2" Angle Brackets.
(8 qty.) #14 x 2 1/2" Stainless Steel Flat Head Screws.

6" Balustrade System Rail Support Block




Part Number	
RSB4X4X6	

Rail Support Blocks should be placed under the Bottom Rail at a span of every 48" or less. These blocks can be trimmed for height.

6" Balustrade System Newel Post

One piece Post reinforced, height trimable.



Part Number	Newel Post Installation Kit* <small>(See Installation Guide Page 33)</small>	
NP8X48	NPK8	

*Hardware included to secure one NP8X48.
(2 qty.) 3/8" - 16 Hex Nuts.
(2 qty.) 3/8" - Lock Washers.
(2 qty.) 3/8" - Flat Washers.
(1 qty.) 1/4" x 6 1/2" Diameter Steel Top Mounting Plate.
(2 qty.) 3/8" x 50" Threaded Rods.
(1 qty.) 1/4" x 3 1/2" x 3 1/2" Octagon Steel Base Plate.
Fasteners to mount Steel Base Plate to floor surface not provided.

